

Pacific Modern Lounge Assembly

1pcs Chair Seat Assembled (With Insert Nuts)

1pcs Chair Back Assembled

2pcs Chair Arms (with Insert Nuts)

1pcs Assembled Footrest (with Insert Nuts)

12pcs 50mm Bolts

Assembly Instructions

1pcs Allen Key

2pcs Chair Front Legs

